

iPod/D.PLAYER専用インターフェースアダプター KS-PD100/500対応機種リスト

:2006年6月1日 追加

機種名	操作タイプ	iPod/D.PLAYER 操作レベル	対応(OK)/ 非対応(NO)
KD-C222-A	-	-	NO
KD-C222-B	-	-	NO
KC-C222-P	-	-	NO
KD-C222-W	-	-	NO
KD-C414-B	-	-	NO
KD-C424-B	B	1	OK
KD-C424-S	B	1	OK
KD-C434-B	B	1	OK
KD-C434-S	B	1	OK
KD-C505-B	B	2	OK
KD-CD404	-	-	NO
KD-CZ500	-	-	NO
KD-CZ502	-	-	NO
KD-CZ603	B	2	OK
KD-DV5000	B	1	OK
KD-DV5000-B	B	1	OK
KD-DV5100-B	B	1	OK
KD-DV5100-S	B	1	OK
KD-DV5200-B	B	1	OK
KD-DV5200-S	B	1	OK
KD-DV6100-S	B	1	OK
KD-DV6200-S	B	2	OK
KD-LH2000	-	-	NO
KD-LH300	B	1	OK
KD-LHX500-B	E	1	OK
KD-LHX500-S	E	1	OK
KD-M515-A	-	-	NO
KD-M515-B	-	-	NO
KD-M515-D	-	-	NO
KD-M515-P	-	-	NO
KD-M515-S	-	-	NO
KD-M515-V	-	-	NO
KD-M525-B	-	-	NO
KD-M525-S	-	-	NO
KD-M535-B	-	-	NO
KD-M535-S	-	-	NO
KD-M545-A	-	-	NO
KD-M545-P	-	-	NO
KD-M545-W	-	-	NO
KD-M550	-	-	NO
KD-MZ302	-	-	NO
KD-PAV7000	E	1	OK
KD-SD700	C	1	OK
KD-SH919-B	B	1	OK
KD-SH919-S	B	1	OK
KD-SHX929	C	1	OK
KD-VZ800	B	1	OK
KD-VZ801	B	2	OK
KW-AVX700	C	2	OK
KW-MC26	B	1	OK
KW-MC300	B	2	OK
KW-MC33-B	B	1	OK
KW-MC33-S	B	1	OK
KW-MC34	B	1	OK
KW-MC35-B	B	1	OK
KW-MC35-S	B	1	OK
KW-MC36-B	B	1	OK
KW-MC36-S	B	1	OK
KW-MC37-B	B	2	OK
KW-MC37-S	B	2	OK
KW-MZ610	B	1	OK
KW-MZ620	B	1	OK
KW-MZ630	B	1	OK
KW-MZ640	B	2	OK
KW-SH505-S	B	1	OK
KW-SH800	B	1	OK
KW-SH800-B	B	1	OK
KW-TC310	B	1	OK